


**Soffi-Steel® System
Clip Release Tool**

* The Shield Clip Release Tool is used to remove the shield after it has been installed



Grice Engineering Inc.
Clip Release Tool
Drawn By: S.P.S.